

AIR MATRIX UPDATE Micro-SD

By [MatrixCamAirMan](#) | March 30, 2011

Material:

- Update file.
- Micro-SD card formatted in FAT32
- Pcmcia compatible receiver type MATRIX (Reload, Reborn).

Procedure:

The update file consists of 5 files:

- mca.ini
- mca_card.bin
- mcaboot.ini
- rootfs.jffs2
- mca_cam_v0222.upb (this file is the change depends on the firmware that say, always extension UPB)

1. These five files are copied in our Micro-SD (Root).
2. We put the receiver in an unencrypted channel (important).
3. With our MATRIX AIR without putting in the receiver, we introduce the Micro-SD slot on the side of the pcmcia
4. The support of the micro-sd is anchor so just enter this and we hear the locking click.
5. We MATRIX MICRO AIR + SD in the PCMCIA slot of our receiver. The recipient must recognize the pcmcia.
6. AIR MATRIX flashing blue LED lights her for a few seconds then going to turn the red LED turning right and ending the two red LED lights.
7. At this point if we ask for "info" to our pcmcia receiver shows "Initializing system! Please wait! "
8. Without touching anything else, hopefully this is finished, MATRIX-AIR LED lights flashing blue and red, going after a few seconds to turn the two red LEDs permanently.
9. At this point if we ask for "info" to the receiver shows: "Please do not touch! It Will Be Automatically upgrade. Wait around 6 minutes "
10. Some receiver models indicate that the process is finished (it is normal not provided)
11. Without touching anything expect about 6 minutes and removed the receiver pcmcia: We take the Micro-SD pcmcia and we put all the MATRIX-AIR receiver. AIR MATRIX-to-date